




MAXIM 3000® UNIT ACCESSORY LOCATIONS



The following will be the standard locations for accessories when assembled by Satellite Industries




Location “A”	PAPERGUARD Right panel, see Maxim 3000 unit assembly instructions P/N 17674.	2 PAPERGUARD PER UNIT Right panel, mount lower paperguard see unit assembly instructions P/N 17674. Mount upper paperguard 2 ¼” directly above lower paperguard.	3 ROLL PAPERGUARD Right panel, see 3 roll paperguard installation instructions P/N 18142
			

Location “B”	PAPERGUARD WITH HANDWASH MAX3000 Left panel, SEE UNIT ASSEMBLY INSTRUCTIONS P/N 17674.	PAPERGUARDS /2 PER UNIT WITH MAX3000 HANDWASH. Mount lower paperguard in the same location as unit with HANDWASH MAX 3000 with single paperguard. Mount upper paperguard 2” directly above lower paperguard.
		

Location “B”	3 ROLL PAPERGUARD / WITH MAX3000 HANDWASH Right panel, see 3 roll paperguard installation instructions P/N 18142
	

MAXIM 3000® UNIT ACCESSORY LOCATIONS

	SOAP/SANITIZER DISPENSERS Right facing (hasp side) See PN#18432 Instruction.		SOAP/SANITIZER DISPENSERS Left facing, (hinge side) over the Urinal (centered), 53" to top hole from floor.
Location "A"		Location "B"	

Location other options	HANDWASH MAX3000 Right front corner of unit. Mount per installation instructions P/N 17085.	SHELF Right rear corner, see shelf installation instructions P/N 18533.	PAPER TOWEL DISPENSER Right panel, see paper towel dispenser installation instructions P/N 12798.
			

Location "A"	MIRROR Right Panel, see mirror installation instructions P/N 17936.	Location "B"	MIRROR Door, see mirror installation instructions P/N 17936.
			



SATELLITE INDUSTRIES, INC.

2530 Xenium Lane North, Minneapolis, MN 55441
Telephone: 763-553-1900 Fax: 763-553-1905
800-328-3332 / www.satelliteindustries.com